Replacement Parts Diagram
AF501 Air Scrubber
115VAC, 60HZ Operation



Replacement Parts Diagram
Front Housing Cover
AF501 Air Scrubber
[Beginning with Serial Number 175316]



Replacement Parts Diagram
Front Housing Cover
AF501 Air Scrubber
[Beginning with Serial Number 175316]

Reference Number	Part Number	Description	Quantity
1	AF501-0040	Cover, Housing	Not Serviced
2	AF501-0170	Cover, Inlet	1
3	AF501-0110	Clip, Latch	2
4	17050010	Washer, Flat, M5, Z	4
5	AF501-0190	Clamp, Filter, Primary	2
6	AF500-0310	Clamp, Lanyard	1
7	AF501-0250	Lanyard, Cover, Inlet	1
8	23041000	Pin, Clevis, 1/4 X 1-1/4, ZY	1
9	49040000	Washer, Fender, 1/4, Z	2
10	KIC-172	Ring, Kickout	1
11	37051010	PHMS, M5-0.8 X 10, Z	4
12	AF501-0260	Screw, Self Tap, #9 X 5/8, Z	4
13	15057610	HHCS, M5-0.8 X 76, Z	2
14	90050010	Nut, Acorn, M5-0.8, Z	2
15	AF501-0180	Screw, Self Tap, #7 X 7/16, Z	1
16	GECD-5040	Decal, General, 2.31 X 12.00	1
17	AF501-0270	Gasket, Cover, Housing	1

Replacement Parts Diagram
Main Housing
AF501 Air Scrubber
[Beginning with Serial Number 175316]



Replacement Parts Diagram
Main Housing
AF501 Air Scrubber
[Beginning with Serial Number 175316]

Reference Number	Part Number	Description	Quantity
1	AF501-0050	Housing, Motor	Not Serviced
2	AF501-0070	Screen, Outlet	1
3	AF501-0120	Latch, Cover	2
4	AF501-0090	Plate, Mounting, Motor	1
5	AF501-0080	Assembly, Fan/Motor	1
6	AF501-0060	Screen, Inlet	1
7	AF501-0200	Port, Vacuum	1
8	AF501-0140	Assembly, Switch, On/Off	1
9	AF501-0130	Assembly, Receptical	1
10	EP8ACP-0120	Relief, Strain	1
11	AF501-0100	Cord, Power, US	1
12	AF501-0160	Switch, Pressure	1
13	AF501-0220	Hose, Vacuum	2
14	AF501-0300	Lamp, Indicator, Filter	1
15	AF501-0150	Capacitor, Motor	1
16	37051010	PHMS, M5-0.8 X 10, Z	8
17	AF501-0180	Screw, Self Tap, #7 X 7/16, Z	19
18	17050010	Washer, Flat, M5, Z	6
19	AF501-0210	Screw, Self Tap, #4 X 7/16, Z	4
20	VS220-5020	Decal, Warning, Silica	1
21	GECD-5060	Decal, Warning, Prop 65	1
22	SG24-5072	Decal, Assistance	1
23	AF501-0290	Breaker, Circuit	1
24	AF501-0310	Knob, Power	1

Replacement Parts Diagram
Replacement Air Filters
AF501 Air Scrubber
[Beginning with Serial Number 175316]



Replacement Parts Diagram
Replacement Air Filters
AF501 Air Scrubber
[Beginning with Serial Number 175316]

Reference Number	Part Number	Description	Quantity
1	AF501-0010PAK3	Pack3, Filter, Main	1
2	AF501-0020	Filter, HEPA	1
3	AF501-0030PAK2	Pack2, Filter, Odor	1

Replacement Parts Diagram
Air Scrubber Accessories
AF501 Air Scrubber



Reference Number	Part Number	Description	Quantity
1	RB16PAK10	Pak10, Band, Rubber, 16D	10
2	LFD16100	Duct, Flat, Lay, 16D, 1200L, (Includes Ref. 1)	1